

HomeSeer HS3-Pi Install Guide

This guide will allow you as the user to use your Raspberry Pi to run HS3. When installed on the Raspberry Pi3, HS3-Pi creates an ultra-small, powerful Z-Wave home automation gateway controller.

Requirements:

- Raspberry Pi2 or Pi3
- Blank SD Card of 8GB
- SD Card reader

Downloads:

- [HomeSeer Rasp-Pi Image](#)
- [Win32DiskImager](#)

Procedure:

1. Download the *HomeSeerPi.zip* from the link above.
2. Once the download is finished, extract the *Pi3-042318* file from the zip folder. This may take up to 10 minutes.
3. Download, install, and run Win32DiskImager.
4. Insert blank SD card into SD card reader.
5. Select the *Pi3-042318* file and the correct drive letter of your SD card. Click Write.
6. Once finished remove SD card and insert into your Pi3.
7. Boot up will take about a minute. Go to find.homeseer.com to start using HS3!

[Click here](#) for the complete HS3 Quick-Start Guide.

Troubleshooting Rasp-Pi

All customers have lifetime support. Initially you have **30 Day Priority Phone Support** and after that you have support through our **Help Desk** (helpdesk.homeseer.com) and our community based **Message Board** (board.homeseer.com).

HomeSeer Technologies
10 Commerce Park North, Unit #10
Bedford, NH 03110
www.homeseer.com
603-471-2816

